

I'm not a bot





























[illegible]



Disconnect the battery negative terminal before connecting or disconnecting each connector or terminal. Carry out the following error check procedures for error diagnosis.(1) Disconnect the battery negative terminal for more than 60 seconds (All error codes are cleared).(2) Reconnect the battery negative terminal.(3) Start the engine\*, check whether or not there is the error. If engine SST is used, see the troubleshooting process of the exclusive engine code P2138 in the 1ZS Repair Manual.Note: Keep the engine idling speed for 3 seconds, put the accelerator pedal to the fullest gradually over 3 seconds, and keep the engine maximum speed for 3 seconds.Probable cause: Harness defect Accelerator pedal position sensor defect Engine controller defect E C4-6 Accelerator pedal position sensor range abnormality (4Y)Probable cause: Connector contact defect Accelerator pedal position sensor defect Harness defect Engine controller defect E C4-6 Accelerator pedal position sensor range abnormality (1ZS)CAUTION: Disconnect the battery negative terminal before connecting or disconnecting each connector or terminal. Carry out the following error check procedures for error diagnosis.(1) Disconnect the battery negative terminal for more than 60 seconds (All error codes are cleared).(2) Reconnect the battery negative terminal.(3) Start the engine\* , check whether or not there is the error. If engine SST is used, see the troubleshooting procedure of the exclusive engine code P2121 in the 1ZS Repair Manual.Note: Keep the engine idling speed for 3 seconds, put the accelerator pedal to the fullest gradually over 3 seconds, and keep the engine maximum speed for 3 seconds.Probable cause: Harness defect Accelerator pedal position sensor defect Engine controller defect E C4-7 Accelerator pedal position sensor 1 circuit malfunctionCAUTION: Disconnect the battery negative terminal before connecting or disconnecting each connector or terminal. Carry out the following error check procedures for error diagnosis.(1) Disconnect the battery negative terminal for more than 60 seconds (All error codes are cleared).(2) Reconnect the battery negative terminal.(3) Start the engine\*, check whether or not there is the error. If engine SST is used, see the troubleshooting procedure of the exclusive engine code P2120 in the 1ZS Repair Manual.Note: Keep the engine idling speed for 3 seconds, put the accelerator pedal to the fullest gradually over 3 seconds, and keep the engine maximum speed for 3 seconds.Probable cause: Harness defect Accelerator pedal position sensor defect Engine controller defect E C4-8 Accelerator pedal position sensor 2 circuit malfunctionCAUTION: Disconnect the battery negative terminal before connecting or disconnecting each connector or terminal. Carry out the following error check procedures for error diagnosis.(1) Disconnect the battery negative terminal.(3) Start the engine\*, check whether or not there is the error. If engine SST is used, see the troubleshooting procedure of the exclusive engine code P2125 in the 1ZS Repair Manual.Note: Keep the engine idling speed for 3 seconds, put the accelerator pedal to the fullest gradually over 3 seconds, and keep the engine maximum speed for 3 seconds.Probable cause: Harness defect Accelerator pedal position sensor defect Engine controller defect E C7-1 Shift lever forward and reverse travel switch open abnormalityTravel return to neutral operation disabledPartial limitation of the drive control functionCAUTION: The above chart is for vehicles of the armrestspecification, Y46, Y45 and Y41 should be used.For vehicles of the EZ PEDAL specification , A781, A782 and A783 should be used.In the event that the engine stops while travelling, when the ignition key switch is turned from OFF toON, an C71 error may be detected, however this is not a fault. Stop the vehicle, turn the ignition key switch OFF and restart the engine.Probable cause: Connector contact defect Forward travel shift switch defect Reverse travel shift switch defect Harness defect Shift switch installation defect SAS/OPS controller (w/SAS) or OPS controller (wo/SAS) defect Shift switch defect E C7-2 Shift lever forward and reverse travel switches simultaneously ON errorTraveling may stopPartial limitation of the drive control function.CAUTION: The above chart is for vehicles of the left shift lever column specification. For vehicles of the armrest specification, Y46, Y45 and Y41 should be used. For vehicles of the EZ PEDAL specification , A781, A782 and A783 should be used.Probable cause: Connector contact defect Forward travel shift switch defect Reverse travel shift switch defect Harness defect Shift switch installation defect SAS/OPS controller (w/SAS) or OPS controller (wo/SAS) defect Forward travel relay defect Reverse travel relay defect Reverse travel relay defect SAS/OPS controller (w/SAS) defect E CB-1 Power off relay open circuit or load short abnormalityTraveling disabled, Material handling and power steering disabled (solenoid off)Probable cause: Connector contact defect Engine auto stop relay harness defect Engine auto stop relay defect SAS/OPS controller defect E CB-2 MB contactor fusedDisplay only E E1-1 PCR current sensor offset abnormalityMaterial handling and power steering disabled E E1-2 PCR: OvercurrentMaterial handling and power steering disabled E E2-1 Pump motor overheatRestricted material handling output E E2-2 Pump motor thermo-sensor abnormalityRestricted material handling output E E3 PCR main drive circuit thermo-sensor abnormalityRestricted material handling output E E8 Pump motor rpm sensor abnormalityMaterial handling disabled E EC-1 Unload solenoid open circuit or load short abnormalityTraveling and material handling enabled even after leaving the seatProbable cause: Connector contact defect Harness defect Unload solenoid defect SAS/OPS controller (w/SAS) or OPS controller (wo/SAS) defect E EE-1 Communication abnormality from display to C/R (1)Display only E EE-2 Communication abnormality from display to C/R (2)Display only E EE-3 Communication abnormality from display to C/R (3)Operate under the default E EF-1 EEPROM abnormality (1)Operate under the default E EF-2 EEPROM abnormality (2)Operate under the default E EF-3 CPU abnormalityDisplay only E EF-4 EEPROM abnormality (3)Operate under the default E F1-1 SAS/OPS data reception error /Communication abnormality from C/R to display (1)/Display onlyProbable cause: Connector contact defect Harness defect Combination meter defect SAS/OPS controller (w/SAS) defect E F4-1, F4-2, F4-3, F4-4, F4-5, F4-6, F4-7, F4-8 CPU errorDisplay not stableProbable cause: Multifunction display board defect E FF D15V overcurrentDisplay off E H1-1 Lift lever potentiometer open abnormalityLift operation onlyProbable cause: Connector contact defect Harness defect Combination meter defect SAS/OPS controller (w/SAS) defect E F4-1, F4-2, F4-3, F4-4, F4-5, F4-6, F4-7, F4-8 CPU errorDisplay not stableProbable cause: Multifunction display board defect E FF D15V overcurrentDisplay off E H1-1 Lift lever potentiometer open abnormalityLift operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Lift lever potentiometer harness defect Lift lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H1-2 Lift lever potentiometer VCC short abnormalityLift operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Lift lever potentiometer harness defect Lift lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H1-3 Lift lever potentiometer assembly errorLift operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Lift lever potentiometer harness defect Lift lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H1-4 Lift lever potentiometer neutral abnormalityMaterial handling disabled / Lift operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Lift lever potentiometer harness defect Lift lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H1-5 Lift lever potentiometer matching value abnormalityLift operation stopProbable cause: Lift lever angle value is outside the specified range for matching E H2-1 Tilt lever potentiometer open abnormalityTilt operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Tilt lever potentiometer harness defect Tilt lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H2-2 Tilt lever potentiometer VCC short abnormalityTilt operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Attachment 1 lever potentiometer harness defect Attachment 1 lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H3-2 Attachment 1 lever potentiometer VCC short abnormalityAttachment 1 operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Attachment 1 lever potentiometer harness defect Attachment 1 lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H3-3 Attachment 1 lever potentiometer combination errorAttachment 1 operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Attachment 1 lever potentiometer harness defect Attachment 1 lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H3-4 Attachment 1 lever potentiometer neutral abnormalityMaterial handling disabled / Attachment 1 operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Attachment 1 lever potentiometer harness defect Attachment 1 lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H3-5 Attachment 1 lever potentiometer matching value abnormalityAttachment 1 operation stopProbable cause: Attachment 1 lever angle value is outside the specified range for matching E H4-1 Attachment 2 lever potentiometer open abnormalityLever 2 operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Attachment 2 lever potentiometer harness defect Attachment 2 lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H4-2 Attachment 2 lever potentiometer VCC short abnormalityLever 2 operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Attachment 2 lever potentiometer harness defect Attachment 2 lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H4-3 Attachment 2 lever potentiometer combination errorLever 2 operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Attachment 2 lever potentiometer harness defect Attachment 2 lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H4-4 Attachment 2 lever potentiometer neutral abnormalityMaterial handling disabled / Lever 2 operation stopCAUTION: If the lever has been removed, be sure to perform matching after the lever is reinstalled.Probable cause: Connector contact defect Attachment 2 lever potentiometer harness defect Attachment 2 lever potentiometer defect SAS/OPS/mini lever controller defect Fuse defect E H4-5 Attachment 2 lever potentiometer matching value abnormalityLever 2 operation stopProbable cause: Attachment 2 lever angle value is outside the specified range for matching E H5-1 Lift PUSH solenoid open abnormalityProbable cause: Connector contact defect Lift PUSH solenoid harness defect Lift PUSH solenoid defect SAS/OPS/mini lever controller defect E H5-3 Lift a1 (DOWN) solenoid abnormality (1)Lift operation stop E H5-4 Lift a1 (DOWN) solenoid abnormality (2)Material handling disabled E H5-5 Lift solenoid drive circuit abnormalityMaterial handling disabled E H6-1 Tilt PUSH solenoid open abnormalityTilt operation stopProbable cause: Connector contact defect Tilt PUSH solenoid harness defect Tilt PUSH solenoid defect SAS/OPS/mini lever controller defect E H6-2 Tilt PULL solenoid open abnormalityMaterial handling disabled / Tilt may stopProbable cause: Connector contact defect Tilt PULL solenoid harness defect Tilt PULL solenoid defect SAS/OPS/mini lever controller defect E H6-3 Tilt b2 (REAR) solenoid abnormality (1)Tilt operation stop E H6-4 Tilt b2 (REAR) solenoid abnormality (2)Material handling disabled E H6-5 Tilt solenoid drive circuit abnormalityMaterial handling disabled E H7-1 Attachment 1 PUSH solenoid open abnormalityAttachment 1 operation stopProbable cause: Connector contact defect Attachment 1 PUSH solenoid harness defect Attachment 1 PUSH solenoid defect SAS/OPS/mini lever controller defect E H7-2 Attachment 1 PULL solenoid open abnormalityMaterial handling disabled / Attachment 1 may stopProbable cause: Connector contact defect Attachment 1 PULL solenoid harness defect Attachment 1 PULL solenoid defect SAS/OPS/mini lever controller defect E H7-3 Attachment 1 b3 solenoid abnormality (1)Attachment 1 operation stop E H7-4 Attachment 1 b3 solenoid abnormality (2)Material handling disabled E H7-5 Attachment 1 solenoid drive circuit abnormalityMaterial handling disabled E H8-1 Attachment 2 PUSH solenoid open abnormalityAttachment 2 operation stopProbable cause: Connector contact defect Attachment 2 PUSH solenoid harness defect Attachment 2 PUSH solenoid defect SAS/OPS/mini lever controller defect E H8-2 Attachment 2 PULL solenoid open abnormalityMaterial handling disabled / Attachment 2 may stopProbable cause: Connector contact defect Attachment 2 PULL solenoid harness defect Attachment 2 PULL solenoid defect SAS/OPS/mini lever controller defect E H8-3 Attachment 2 b4 solenoid abnormality (1)Attachment 2 operation stop E H8-4 Attachment 2 b4 solenoid abnormality (2)Material handling disabled E H8-5 Attachment 2 solenoid drive circuit abnormalityMaterial handling disabled E H9-1 Unload valve solenoid openMaterial handling disabled E H9-2 Unload valve solenoid shortMaterial handling disabled E H9-3 Unload valve solenoid drive circuit abnormalityMaterial handling disabled E HA-1 3/4 way change relay GND short abnormalityAttachment switching disabled

**Toyota e50 error. Toyota forklift error code e50. Toyota forklift error codes. Toyota forklift error code e01-5. Toyota forklift error code list. E50 error code toyota.**