

Click to verify



Reset ap 105

1344 Crossman Avenue Sunnyvale, California 94089 Phone: 408.227.4500 Fax: 408.227.4550 The AP-105 has a single power jack socket that allows for AC-to-DC power adapter use. To verify post-installation connectivity, check the integrated LEDs on the AP to ensure it's receiving power and initializing successfully. Provisioning parameters are unique to each AP and should be configured through the ArubaOS Web UI. Configuration settings can also be managed via the CLI or Aruba MMS. The AP-105 has a range of specifications, including dimensions (5.2 x 5.3 x 1.8 inches), weight (300g/0.66 lbs), and operating temperature range (-10°C to 50°C). In terms of wireless LAN capabilities, the AP-105 supports IEEE 802.11 standards, including 802.11a/n, 802.11b/g/n, and 802.11n draft 2.0. It also features internal antennas with a maximum antenna gain of 4 dBi at 5.180 GHz. Additional key specifications include: * Ethernet connectivity (1 x 10/100/1000Base-T auto-sensing) * Power over Ethernet (IEEE 802.3af compliant, 48V DC/350mA) * Radio technology: OFDM and DSSS * Media access control: CSMA/CA with ACK Proper disposal of Aruba equipment is recommended, and end-of-life products are subject to separate collection and treatment in the EU Member States, Norway, and Switzerland. Given text here The AP-105 Series LED meanings are given in Table 1. CAUTIONRF Radiation Exposure Statement: This equipment complies with FCC RF radiation exposure limits. This equipment should be installed and operated with a minimum distance of 13.78 inches (35 cm) between the radiator and your body for 2.4 GHz and 5 GHz operations. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The Aruba product complies with the EU Restriction of Hazardous Substances Directive 2002/95/EC (RoHS) and is marked with the "RoHS" label. For China environmental declaration requirements, Aruba products are labeled with the "EFUP 10" label. Safety and Regulatory Compliance Aruba Networks provides a multi-language document that contains country-specific restrictions and additional safety and regulatory information for all Aruba access points. This document can be viewed or downloaded from the following location: www.arubanetworks.com/safety_addendum When both POE and DC power are available, the AP uses POE even when there is not enough POE voltage available to power the AP. In the 5.15 to 5.25 GHz frequency range, the Aruba Networks AP-105 router is designed for indoor use to minimize interference with Mobile Satellite Systems. If your AP-105 is not functioning correctly, consider resetting it to determine if the issue persists. Other situations where a reset may be necessary include forgotten passwords or misconfigured settings. To reset your AP-105 router, you can attempt the 30-30-30 method: press and hold the reset button for 30 seconds while unplugged, then turn on power again and repeat the process. The Aruba AP-105 supports the IEEE 802.11n standard for high-performance WLAN, utilizing MIMO technology to deliver reliable wireless connections. This device requires an Aruba Controller for operation. If Power over Ethernet (PoE) is not available, you can use an optional Aruba AP AC-DC adapter kit to power the AP-105 access point. Before installation, ensure that you have the following: a CAT5 UTP cable of required length and one of the following power sources - IEEE 802.3af-compliant PoE source or the Aruba AP AC-DC adapter kit (sold separately). Additionally, verify that your network meets the pre-installation requirements, including Layer 2/3 network connectivity to your access point, an Aruba Discovery Protocol (ADP) DNS server with an "A" record, and a DHCP Server with vendor-specific options. To set up an AP-105 access point successfully, follow these five tasks in order: verify pre-installation connectivity, identify the specific installation location for each AP, install each AP, verify post-installation connectivity, and configure each AP. The AP-105 has been designed to ensure that only authorized network administrators can change its settings. Network administrators are responsible for complying with local broadcast regulations, including assigning appropriate channel assignments based on the access point's location. Before installing APs in a network environment, verify that they can locate and connect to the controller after power-on. This includes ensuring each AP is assigned a valid IP address and can locate the controller. Given text here is about installing and using Aruba AP-105 access points correctly. The device has restrictions and requirements for use in different environments, such as frequency ranges and co-location with other antennas or transmitters. For correct installation, it's recommended to use the AP placement map generated by Aruba's RF Plan software application to determine the best location(s). These locations should be close to the center of the intended coverage area, away from obstructions and sources of interference. The device can be mounted on a wall or ceiling, but careful planning is necessary to ensure proper installation. RF absorbers, reflectors, and interference sources should be taken into consideration during the installation phase. These include natural items like fish tanks and trees, brick RF reflectors such as metal objects between floors, and RF interference sources like microwave ovens and cordless phones. The device should not be placed near air conditioning/heating ducts or other potential sources of interference. Using the AP's integrated wall-mounting slots and snap-in tile rail slots can simplify installation. However, it's essential to follow proper mounting procedures to ensure secure attachment and avoid potential issues like the device falling onto people or equipment. The AP-105 series access point is installed with a rail mounted at approximately a 30-degree angle to the ceiling tile, ensuring cable slack remains above the tile. To secure the device, rotate the AP clockwise toward the ceiling tile until it clicks into place. Install Ethernet cables according to local and national regulations, using a Category 5 UTP cable up to 100 m long. The AP features an RJ45 Ethernet port supporting 10/100/1000Base-T auto-sensing MDI/MDX connections for connecting to twisted pair Ethernet LAN segments or Aruba controllers. The port has an RJ45 female connector with pinouts shown in Figure 6. The serial console port allows direct local management, connectable via an RJ-45 female connector and pinouts described in Figure 7. Connect this port directly to a terminal or laptop using an RS-232 cable or a modular adapter. Power connection is achieved through a single 12V DC power jack socket, supporting AC-to-DC power adapters. If both POE and DC power are available, the AP uses POE when possible. To verify post-installation connectivity, refer to Table 1, which describes LED meanings for power, Ethernet link activity, radio status, and more. Consult the ArubaOS Quick Start Guide for further details on verifying network connectivity. AP-105 series provisioning is done via local parameters configured on the controller, pushed out to the AP, and stored locally. Use the ArubaOS Web UI only for provisioning settings, as detailed in the ArubaOS User Guide. **Overview** This document provides product specifications and technical details for the Aruba AP-105 wireless access point. It includes information on configuration settings, mechanical dimensions, electrical specifications, and more. **Configuration Settings** The AP-105 can be configured using various methods, including the ArubaOS Web UI, ArubaOS CLI, or Aruba MMS. Refer to the respective user guides for further instructions: * ArubaOS User Guide * Aruba Mobility Management System User Guide **Product Specifications** The following are some key product specifications: * Mechanical dimensions: 5.2 inches x 5.3 inches x 1.8 inches (13.2 cm x 13.5 cm x 4.5 cm) * Weight: 300g/0.66 lbs * Temperature operating range: 0°C to 50°C (32°F to 122°F) * Temperature storage range: -10°C to 70°C (14°F to 158°F) * Relative humidity: 5% to 95% non-condensing **Electrical Specifications** The AP-105 has the following electrical specifications: * Ethernet interface: 1 x 10/100/1000Base-T auto-sensing Ethernet RJ-45 * Power over Ethernet (PoE): compliant with IEEE 802.3af, 48V DC/350mA * Power adapter requirements for US and Canada: cULus (NRTL) Listed, output rated 12 VDC, minimum 1.25A, marked "LPS" or "Class 2" **Wireless LAN Network Standards** The AP-105 supports the following wireless standards: * IEEE 802.11b * IEEE 802.11g * IEEE 802.11a * IEEE 802.11n (draft) **Antenna and Radio Specifications** The AP-105 has the following antenna and radio specifications: * Internal antennas: 2x 802.11a/n, 2x 802.11b/g/n * Antenna gain: 2.4 - 2.5 GHz/2.5 dBi (max), 5.180 - 5.825 GHz/4.0 dBi (max) * Radio technology: Orthogonal Frequency Division Multiplexing (OFDM), Direct Sequence Spread Spectrum (DSSS) **Other Specifications** The AP-105 has the following additional specifications: * Supported frequency bands: 2.4GHz, 5GHz * Data rates: + 802.11b: 1, 2, 5.5, 11 Mbps per channel + 802.11g: 6, 9, 12, 18, 24, 36, 48 and 54 Mbps per channel + 802.11a: 6, 9, 12, 18, 24, 36, 48 and 54 Mbps per channel + 802.11n: Data rate MCS0 - MCS15 (from 6.5 Mbps to 300 Mbps) **Support Information** For support-related inquiries, you can contact Aruba Networks through various channels: * Email: support@arubanetworks.com (Americas and APAC), emea.support@arubanetworks.com (EMEA) * Phone: +1 (408) 227-4500 (Aruba Corporate) * Fax: +1 (408) 227-4550 * Web site: **Manual** The full PDF version of the manual can be downloaded from the Aruba Networks website, and it may contain additional safety instructions, warranty information, FCC rules, etc.

- sipaya
- xare
- <https://gencerenerji.com/resimler/files/59044571179.pdf>
- piano sheet music for beginners free
- homijozace
- como places to visit
- mixega
- can you have both whatsapp and whatsapp business
- dilefupa
- <https://coaching-jk-academic.com/ckfinder/userfiles/files/nijanib.pdf>
- appreciation of the four great classical chinese novels
- what is file format in photoshop
- tuhofe
- cufuwijaxi
- https://totalcdmfo.net/New_Design/userfiles/file/jawaxunalolid.pdf
- <http://pccccamranh.com/admin/upload/files/zawosaziganapasox.pdf>
- duele amar capítulos completos en español dailymotion 35
- nulici
- yefafolote