


Click to prove
you're human



You can customize your Android device with accessibility settings and apps. Content Use a screen reader with TalkBack Change your display Interaction controls Use a braille display Use Pixel’s Magnifier Captions Audio Explore Android accessibility apps and services Design and develop more accessible apps Get help Use a screen reader with TalkBack To interact with your device with touch and spoken feedback, you can turn on theTalkBack screen reader. TalkBack describes your actions and tells you about alerts and notifications. You can use the TalkBack braille keyboard to enter 6-dot braille on your screen. TalkBack braille keyboard is available in Unified English Braille, Spanish, and Arabic. Change your display Display size and font size: To change the size of items on your screen, adjust the display size or font size. Magnification: To temporarily zoom or magnify your screen, use magnification. Contrast and color options: To adjust contrast or colors, you can use: Select to Speak: If you want spoken feedback at certain times, you can turn on Select to Speak. Select items on your screen, or point your camera at something to hear it read or described aloud. Interaction controls Lookout uses computer vision to give people who are visually impaired or have low vision information about their surroundings. Voice Access lets you control your device with spoken commands. Use your voice to open apps, navigate, and edit text. Switch Access lets you interact with your Android device with one or more switches instead of the touchscreen. You can use a switch or keyboard to control your device. Action Blocks let you use customizable buttons for routine actions on your Android home screen. Time to take action lets you choose how long to show messages that ask you to take action. Use a braille display Important: BrailleBack is no longer required to connect to a braille display. With the TalkBack braille keyboard, you can use 6 fingers on your screen to enter 6-dot braille. TalkBack braille keyboard is available in Unified English Braille, Spanish, and Arabic. Use Pixel’s Magnifier Important: To use the Magnifier app, you can download it from the Google Play Store. The Magnifier app is only available on Pixel 5 and later devices, except Pixel Tablet or Pixel Fold. Magnifier lets you use your device to read fine text or get an up-close view of craft projects. With the Magnifier app, you can take photos and zoom in on distant objects. You can use Magnifier to view things at a distance like street signs or view the stage at a concert or event. Learn more about Pixel’s Magnifier. Captions Audio Sound Amplifier lets you use wired or Bluetooth headphones to filter, augment, and amplify the sounds in your environment or on your Android device. Hearing aid support lets you pair hearing aids with your Android device to hear more clearly. The Audio description toggle on Android TV and Android phones plays audio descriptions of on-screen visualsfor videos that you playon Android devices withAndroid 13 and above. You can find the Audio description toggle in the Accessibility settings for your Android TV or Android phone. Audio description availabilitymay vary by video and provider. Explore Android accessibility apps & services Download Android Accessibility Suite, which includes the Accessibility Menu, Select to Speak, Switch Access, and TalkBack. You can find Android Accessibility Suite on devices with Android 9 and higher. Review Android device settings for ways to customize your device. Open your device's Settings app, then choose Accessibility. Explore Google Play for accessibility apps and services for Android. Design & develop more accessible apps If you design or develop an app, Accessibility Scanner can help you identify opportunities to improve your app for users. You can also refer to Android Accessibility developer resources. Get help For more help with Android Accessibility, contact the Google Disability Support team. Learn how to update your app permissions with step-by-step visual guides. You can allow some apps to use various features on your device, such as your camera or contacts list. An app will send a notification to ask for permission to use features on your device, which you can Allow or Deny. You can also change permissions for a single app or by permission type in your device's settings. On your device, open the Settings app. Tap Apps. Tap the app you want to change. If you can't find it, tap See all apps. Then, choose your app. Tap Permissions. If you allowed or denied any permissions for the app, you'll find them here. To change a permission setting, tap it, then choose Allow or Don't allow. For location, camera, and microphone permissions, you may be able to choose: All the time: For location only. The app can use the permission at any time, even when you're not using the app. Allow only while using the app: The app can use the permission only when you're using that app. Ask every time: Every time you open the app, it'll ask to use the permission. It can use the permission until you're done with the app. Don't allow: The app cannot use the permission, even when you're using the app. Change permissions based on their type You can check which apps have the same permission setting. For example, you can check which apps have permission to check your calendar. On your device, open the Settings app. Tap Security & Privacy Privacy Permission manager. Tap a permission type. If you allowed or denied permission to any apps, you'll find them here. To change an apps permission, tap the app, then choose your permission settings.Types of permissions Below is a list of permissions and what they do when turned on for an app. Calendar: Access your calendar. Call logs: Read and write your phone call log. Camera: Take pictures and record videos. Contacts: Access your contacts. Files: Access all files on your device. Health, Wellness, Fitness: Access health data, records, and sensor info about your vital signs. For devices running Android 15 and below, this may appear as "Body Sensors." Location: Access your devices location. Learn about location settings. Microphone: Record audio. Music and audio: Access music and other audio files on your device. Nearby devices: Find, connect to, and determine the relative position of nearby devices. Learn how to find and set up nearby devices. Notifications: Send notifications. Phone: Make and manage phone calls. Photos and videos: Access photos and videos on your device. Physical activity: Access your physical activity, like walking, biking, driving, step count, and more. SMS: Send and check SMS messages.Automatically remove permissions for unused apps On your device, open the Settings app. Tap Apps. Tap the app you want to change. If you can't find it, tap See all apps. Then, choose your app. Under "Unused app settings," turn on Pause app activity if unused.Disable camera or microphone access on your device On your device, open the Settings app. Tap Security & privacy Privacy Privacy controls. Turn off Camera access or Microphone access. Related resources Download apps to your Android device Post to the help community Get answers from community members Apps are designed for use with supported Android and Chromebook devices and can't be used on Windows or Mac computers. On your device, open the Google Play Store or go toplay.google.comon a web browser. Search or browse for content. Select an item. Select Install or the item's price. Follow the on-screen instructions to complete the transaction and get the content. If you made a purchase before: Select your payment method with the Down arrow . If it's your first purchase: Your payment method will be added to your Google Account. Tip: To change your display language on Google Play, change the language in your Google Account settings. Find apps for your watch, tablet, TV, car, or other device You can use Play store filters to search or browse apps and games that are compatible with each of your devices. On your phone: Open the Google Play app . At the top, search for an app or content. In the dropdown menu, choose a device associated with your account. On your computer: Go to play.google.com. At the top right, click the magnifying glass . Then, search for an app or content. Select thedevice dropdown and choose a device associated with your account. After you follow these steps, in your search results, you'll find the apps that are compatible with your device. Tip: To use the search filter, you must be signed in to an account associated with multiple Android devices. Apps and digital content are connected to your Google Account, not just your device. You don't have to buy them again if you get a new device. You can use them on multiple devices. Learn how to install apps and content from your phone or computer to other devices. Content can't be transferred between accounts If you own multiple accounts, you can't transfer content between accounts on Google Play. If you have multiple accounts on your device, before you complete your purchase, make sure you're signed in to the account you want to use. If you purchased an app on the wrong account, contact the app developer. They may give you a refund for your purchase. Post to the help community Get answers from community members Enviar comentarios sobre...

Stop app apk. Android stop download. Android stop downloading file. アンドロイド apk. Android download stoppen.