

[Click Here](#)





























































Installation Instructions Refrigerator Assembly Instruction Panel Install Instructions Oven and Cooktop Combinations Flush Installation Instructions Installing Oven Under Cooktop Install Instructions for Custom Panel Installers Floor Damage Guide Stainless Steel Panel Install Guide Ventilation Specification Custom Wood Dimension Guide Internet Connectivity Guide Clean and Quiet Guarantee Ventilation Pairing Chart Most Helpful Answer Hey Hillari. Unplug the dryer power cord from the outlet. The bottom panel on the front of the dryer must be removed. Then remove the lint filter located at the bottom/front area of the dryer tumbler (with the door open). Next remove the metal duct just behind the bottom panel (already removed), to expose the thermal fuse on top of the round duct-work. Remove the thermal fuse and test it for continuity using a multi-meter, to confirm it's bad. If you put in your dryer's model number with the term "thermal fuse" and do an online search, you'll find diagrams with parts and locations, replacement videos, and you'll be able to shop for parts. Hope this helps. Good Luck. +1-800-366-7278M-F8:30 am-7:30 pmCentralSat8:30 am-7:30 pmCentralSun9:30 am-7:00 pmCentral+1-888-873-3829M-F7:00 am-9:00 pmCentralSat7:00 am-9:00 pmCentralSun8:00 am-8:00 pmCentralSign up for deals and tips about all that Sears PartsDirect offers, including appliance repair, DIY repair parts, home warranties and more.